


This example shows that the meter is being set at 1600 gallons.



Flow Meter Reset

1. Lift the gold box lid off, slide to two side panels up.
2. Locate the flow meter in the Gold Box attached to the bottom plate.
3. Turn the dial clockwise until the down arrow is pointed (image on left) to where the meter should be set.

Recommended Flow Meter Re-Set Value after filter change:

WET 7 at 1600 Gallons

WET 6, WET 5, WET 3 at 1100 Gallons

Two Reasons for Flow Meter Reset:

1. When you max out your recommended consumption volume set by the manufacturer, "down arrow" is pointed at the flow meter "OFF" position, your water system will shut off for safety reasons. This important indicator requires a full filter change. Login into mywater.springaqua.com or contact customer service (1-888-850-3743) to purchase new filters.
2. After new filter change, old filters swapped out by new filters, a flow meter reset is required.